



## Motorcycle Bed-in Procedure

Warning – New brake pads can take up to 200 miles to completely bed-in, so avoid extreme braking until the pad and rotor achieve sufficient surface contact.

**Metallic** bed-in procedure:

1. After installing new brake pads, make 10 stops from 30 mph to 15 mph.
2. Make an additional 10 stops from 50 mph to 15 mph, with as little time between stops as possible.

**Organic** bed-in procedure:

1. No special bed-in required, but still avoid extreme braking for first 200 miles.